

# TOY-1951-BAC

(6) #8 X 5/8 PHILLIPS SCREWS

(6) #8 "U" NUTS



## 2012 TOYOTA TACOMA BG UPPER GRILLE INSTALL



USING A SCREWDRIVER UNCLIP THE PUSH CLIPS ALONG THE TOP OF THE GRILLE SHELL.



REMOVE BOLTS ON THE TOP OF GRILLE SHELL AS SHOWN.



REMOVE PLASTIC CLIP LOCATED ON RIGHT & LEFT LOWER BACKSIDE OF THE GRILLE SHELL.



IN ORDER TO REMOVE GRILLE SHELL YOU MUST UNCLIP THE SIX PLASTIC TABS ALONG THE BOTTOM OF THE GRILLE SHELL. PULL FORWARD ON THE GRILLE SHELL WHILE UNCLIPPING TAB FROM THE BACK SIDE ONE AT A TIME.



REMOVE GRILLE SHELL FROM VEHICLE.



THE FACTORY GRILLE CENTER NEEDS TO BE CUT OUT. PLEASE REVIEW CUTTING INSTRUCTIONS BEFORE CUTTING GRILLE CENTER.



PROTECT THE GRILLE SHELL FROM GETTING SCRATCHED USING MASKING TAPE. START BY CUTTING THE CENTER SECTION OF THE GRILLE SHELL OUT FIRST



A VIEW AFTER CUTTING THE GRILLE CENTER OUT.



PLACE GRILLE INSERT INTO GRILLE SHELL.



WHILE HOLDING GRILLE INSERT IN PLACE MARK MOUNTING BRACKET CENTER HOLE LOCATIONS.



DRILL HOLES FOR THE GRILLE INSERT MOUNTING SCREWS.



FASTEN INSERT WITH SUPPLIED HARDWARE. INSTALL GRILLE SHELL ONTO VEHICLE..

For further installation details check our website installs

Tel:310-970-0300 Fax:310-970-0400

[www.grillcraft.com](http://www.grillcraft.com)